

Connecting Extension to Clamp Edge

1. Remove screws in orange end cap.
2. Remove end cap.
3. Remove 4 screws (2 on each) from metal bars protruding from extension.
4. Slide connector bars into end of clamp edge. (The bars will slide into the end where the orange end cap was removed)
5. Thread in screws loosely so that the track can move slightly.
6. Set clamp edge on its side, on a flat surface.
7. Confirm that the clamp edge is flat against the surface, then tighten screws completely.
8. Insert orange end cap into end of extension, and re-install screws